

Default transmit messages:

On power up:

Message. Ch. Data.

20:23:16.651 From USB Uno MIDI Interface Control 1 Channel Volume (coarse) 127

20:23:16.651 From USB Uno MIDI Interface Control 1 Pan (coarse) 64

20:23:16.652 From USB Uno MIDI Interface Control 1 Hold Pedal 0

20:23:16.659 From USB Uno MIDI Interface Control 1 Bank Select 0

20:23:16.659 From USB Uno MIDI Interface Control 1 Bank Select (fine) 0

20:23:16.660 From USB Uno MIDI Interface Program 1 1

On entering Setup mode (from Program mode):

20:29:04.181 From USB Uno MIDI Interface Control 1 Controller 9 0

20:29:04.181 From USB Uno MIDI Interface Control 1 Effect Control 1 (coarse) 0

20:29:04.198 From USB Uno MIDI Interface Control 1 Bank Select 0

20:29:04.199 From USB Uno MIDI Interface Control 1 Bank Select (fine) 6

20:29:04.200 From USB Uno MIDI Interface Program 1 3

20:29:04.201 From USB Uno MIDI Interface Control 2 Bank Select 0

20:29:04.201 From USB Uno MIDI Interface Control 2 Bank Select (fine) 0

20:29:04.202 From USB Uno MIDI Interface Program 2 66

On entering Song mode (from Setup mode):

20:30:07.658 From USB Uno MIDI Interface Control 1 Controller 9 0

20:30:07.658 From USB Uno MIDI Interface Control 1 Effect Control 1 (coarse) 0

20:30:07.659 From USB Uno MIDI Interface Control 2 Controller 9 0

20:30:07.660 From USB Uno MIDI Interface Control 2 Effect Control 1 (coarse) 0

20:30:07.661 From USB Uno MIDI Interface Control 1 Hold Pedal 0

20:30:07.662 From USB Uno MIDI Interface Control 2 Hold Pedal 0
20:30:07.667 From USB Uno MIDI Interface Control 1 Bank Select 0
20:30:07.667 From USB Uno MIDI Interface Control 1 Bank Select (fine) 0
20:30:07.668 From USB Uno MIDI Interface Program 1 1
20:30:07.672 From USB Uno MIDI Interface Control 2 Bank Select 0
20:30:07.672 From USB Uno MIDI Interface Control 2 Bank Select (fine) 1
20:30:07.675 From USB Uno MIDI Interface Program 2 124
20:30:07.677 From USB Uno MIDI Interface Control 1 Bank Select 0
20:30:07.680 From USB Uno MIDI Interface Control 1 Bank Select (fine) 0
20:30:07.683 From USB Uno MIDI Interface Program 1 33

On entering Program mode (from Song mode)

20:35:44.178 From USB Uno MIDI Interface Control 1 Channel Volume (coarse) 127
20:35:44.178 From USB Uno MIDI Interface Control 1 Pan (coarse) 64
20:35:44.179 From USB Uno MIDI Interface Control 1 Expression (coarse) 127
20:35:44.180 From USB Uno MIDI Interface Control 2 Channel Volume (coarse) 127
20:35:44.181 From USB Uno MIDI Interface Control 2 Pan (coarse) 64
20:35:44.181 From USB Uno MIDI Interface Control 2 Expression (coarse) 127
20:35:44.182 From USB Uno MIDI Interface Control 3 Channel Volume (coarse) 127
20:35:44.183 From USB Uno MIDI Interface Control 3 Pan (coarse) 64
20:35:44.184 From USB Uno MIDI Interface Control 3 Expression (coarse) 127
20:35:44.185 From USB Uno MIDI Interface Control 4 Channel Volume (coarse) 127
20:35:44.185 From USB Uno MIDI Interface Control 4 Pan (coarse) 64
20:35:44.186 From USB Uno MIDI Interface Control 4 Expression (coarse) 127
20:35:44.187 From USB Uno MIDI Interface Control 5 Channel Volume (coarse) 127
20:35:44.187 From USB Uno MIDI Interface Control 5 Pan (coarse) 64
20:35:44.188 From USB Uno MIDI Interface Control 5 Expression (coarse) 127

20:35:44.189 From USB Uno MIDI Interface Control 6 Channel Volume (coarse) 127

20:35:44.190 From USB Uno MIDI Interface Control 6 Pan (coarse) 64

20:35:44.190 From USB Uno MIDI Interface Control 6 Expression (coarse) 127

20:35:44.191 From USB Uno MIDI Interface Control 7 Channel Volume (coarse) 127

20:35:44.192 From USB Uno MIDI Interface Control 7 Pan (coarse) 64

20:35:44.192 From USB Uno MIDI Interface Control 7 Expression (coarse) 127

20:35:44.194 From USB Uno MIDI Interface Control 8 Channel Volume (coarse) 127

20:35:44.194 From USB Uno MIDI Interface Control 8 Pan (coarse) 64

20:35:44.195 From USB Uno MIDI Interface Control 8 Expression (coarse) 127

20:35:44.196 From USB Uno MIDI Interface Control 9 Channel Volume (coarse) 127

20:35:44.196 From USB Uno MIDI Interface Control 9 Pan (coarse) 64

20:35:44.197 From USB Uno MIDI Interface Control 9 Expression (coarse) 127

20:35:44.198 From USB Uno MIDI Interface Control 10 Channel Volume (coarse) 127

20:35:44.198 From USB Uno MIDI Interface Control 10 Pan (coarse) 64

20:35:44.199 From USB Uno MIDI Interface Control 10 Expression (coarse) 127

20:35:44.200 From USB Uno MIDI Interface Control 11 Channel Volume (coarse) 127

20:35:44.201 From USB Uno MIDI Interface Control 11 Pan (coarse) 64

20:35:44.201 From USB Uno MIDI Interface Control 11 Expression (coarse) 127

20:35:44.202 From USB Uno MIDI Interface Control 12 Channel Volume (coarse) 127

20:35:44.203 From USB Uno MIDI Interface Control 12 Pan (coarse) 64

20:35:44.204 From USB Uno MIDI Interface Control 12 Expression (coarse) 127

20:35:44.204 From USB Uno MIDI Interface Control 13 Channel Volume (coarse) 127

20:35:44.205 From USB Uno MIDI Interface Control 13 Pan (coarse) 64

20:35:44.206 From USB Uno MIDI Interface Control 13 Expression (coarse) 127

20:35:44.207 From USB Uno MIDI Interface Control 14 Channel Volume (coarse) 127

20:35:44.207 From USB Uno MIDI Interface Control 14 Pan (coarse) 64

20:35:44.208 From USB Uno MIDI Interface Control 14 Expression (coarse) 127

20:35:44.209 From USB Uno MIDI Interface Control 15 Channel Volume (coarse) 127

20:35:44.210 From USB Uno MIDI Interface Control 15 Pan (coarse) 64
20:35:44.210 From USB Uno MIDI Interface Control 15 Expression (coarse) 127
20:35:44.211 From USB Uno MIDI Interface Control 16 Channel Volume (coarse) 127
20:35:44.212 From USB Uno MIDI Interface Control 16 Pan (coarse) 64
20:35:44.213 From USB Uno MIDI Interface Control 16 Expression (coarse) 127

On entering Master mode (from Setup mode):

20:33:38.606 From USB Uno MIDI Interface Control 1 Controller 9 0
20:33:38.606 From USB Uno MIDI Interface Control 1 Effect Control 1 (coarse) 0
20:33:38.607 From USB Uno MIDI Interface Control 2 Controller 9 0
20:33:38.608 From USB Uno MIDI Interface Control 2 Effect Control 1 (coarse) 0
20:33:38.609 From USB Uno MIDI Interface Control 1 Hold Pedal 0
20:33:38.610 From USB Uno MIDI Interface Control 2 Hold Pedal 0
20:33:38.616 From USB Uno MIDI Interface Control 1 Bank Select 0
20:33:38.617 From USB Uno MIDI Interface Control 1 Bank Select (fine) 0
20:33:38.617 From USB Uno MIDI Interface Program 1 1
20:33:38.628 From USB Uno MIDI Interface Control 2 Bank Select 0
20:33:38.628 From USB Uno MIDI Interface Control 2 Bank Select (fine) 1
20:33:38.630 From USB Uno MIDI Interface Program 2 124
20:33:38.633 From USB Uno MIDI Interface Control 1 Bank Select 0
20:33:38.634 From USB Uno MIDI Interface Control 1 Bank Select (fine) 0
20:33:38.636 From USB Uno MIDI Interface Program 1 33

On entering Master mode (from Song mode):

20:42:08.400 From USB Uno MIDI Interface Control 1 Channel Volume (coarse) 127
20:42:08.401 From USB Uno MIDI Interface Control 1 Pan (coarse) 64

20:42:08.402 From USB Uno MIDI Interface Control 1 Expression (coarse) 127

20:42:08.402 From USB Uno MIDI Interface Control 2 Channel Volume (coarse) 127

20:42:08.403 From USB Uno MIDI Interface Control 2 Pan (coarse) 64

20:42:08.404 From USB Uno MIDI Interface Control 2 Expression (coarse) 127

20:42:08.405 From USB Uno MIDI Interface Control 3 Channel Volume (coarse) 127

20:42:08.406 From USB Uno MIDI Interface Control 3 Pan (coarse) 64

20:42:08.406 From USB Uno MIDI Interface Control 3 Expression (coarse) 127

20:42:08.407 From USB Uno MIDI Interface Control 4 Channel Volume (coarse) 127

20:42:08.408 From USB Uno MIDI Interface Control 4 Pan (coarse) 64

20:42:08.408 From USB Uno MIDI Interface Control 4 Expression (coarse) 127

20:42:08.409 From USB Uno MIDI Interface Control 5 Channel Volume (coarse) 127

20:42:08.410 From USB Uno MIDI Interface Control 5 Pan (coarse) 64

20:42:08.410 From USB Uno MIDI Interface Control 5 Expression (coarse) 127

20:42:08.411 From USB Uno MIDI Interface Control 6 Channel Volume (coarse) 127

20:42:08.412 From USB Uno MIDI Interface Control 6 Pan (coarse) 64

20:42:08.413 From USB Uno MIDI Interface Control 6 Expression (coarse) 127

20:42:08.414 From USB Uno MIDI Interface Control 7 Channel Volume (coarse) 127

20:42:08.414 From USB Uno MIDI Interface Control 7 Pan (coarse) 64

20:42:08.415 From USB Uno MIDI Interface Control 7 Expression (coarse) 127

20:42:08.416 From USB Uno MIDI Interface Control 8 Channel Volume (coarse) 127

20:42:08.417 From USB Uno MIDI Interface Control 8 Pan (coarse) 64

20:42:08.417 From USB Uno MIDI Interface Control 8 Expression (coarse) 127

20:42:08.418 From USB Uno MIDI Interface Control 9 Channel Volume (coarse) 127

20:42:08.419 From USB Uno MIDI Interface Control 9 Pan (coarse) 64

20:42:08.419 From USB Uno MIDI Interface Control 9 Expression (coarse) 127

20:42:08.420 From USB Uno MIDI Interface Control 10 Channel Volume (coarse) 127

20:42:08.421 From USB Uno MIDI Interface Control 10 Pan (coarse) 64

20:42:08.422 From USB Uno MIDI Interface Control 10 Expression (coarse) 127

20:42:08.422 From USB Uno MIDI Interface Control 11 Channel Volume (coarse) 127
20:42:08.423 From USB Uno MIDI Interface Control 11 Pan (coarse) 64
20:42:08.424 From USB Uno MIDI Interface Control 11 Expression (coarse) 127
20:42:08.425 From USB Uno MIDI Interface Control 12 Channel Volume (coarse) 127
20:42:08.425 From USB Uno MIDI Interface Control 12 Pan (coarse) 64
20:42:08.426 From USB Uno MIDI Interface Control 12 Expression (coarse) 127
20:42:08.427 From USB Uno MIDI Interface Control 13 Channel Volume (coarse) 127
20:42:08.428 From USB Uno MIDI Interface Control 13 Pan (coarse) 64
20:42:08.428 From USB Uno MIDI Interface Control 13 Expression (coarse) 127
20:42:08.429 From USB Uno MIDI Interface Control 14 Channel Volume (coarse) 127
20:42:08.430 From USB Uno MIDI Interface Control 14 Pan (coarse) 64
20:42:08.430 From USB Uno MIDI Interface Control 14 Expression (coarse) 127
20:42:08.431 From USB Uno MIDI Interface Control 15 Channel Volume (coarse) 127
20:42:08.432 From USB Uno MIDI Interface Control 15 Pan (coarse) 64
20:42:08.433 From USB Uno MIDI Interface Control 15 Expression (coarse) 127
20:42:08.434 From USB Uno MIDI Interface Control 16 Channel Volume (coarse) 127
20:42:08.434 From USB Uno MIDI Interface Control 16 Pan (coarse) 64
20:42:08.435 From USB Uno MIDI Interface Control 16 Expression (coarse) 127

On entering MIDI mode (from setup mode):

20:42:42.619 From USB Uno MIDI Interface Control 1 Controller 9 0
20:42:42.621 From USB Uno MIDI Interface Control 1 Effect Control 1 (coarse) 0
20:42:42.621 From USB Uno MIDI Interface Control 2 Controller 9 0
20:42:42.621 From USB Uno MIDI Interface Control 2 Effect Control 1 (coarse) 0
20:42:42.622 From USB Uno MIDI Interface Control 1 Hold Pedal 0
20:42:42.623 From USB Uno MIDI Interface Control 2 Hold Pedal 0
20:42:42.630 From USB Uno MIDI Interface Control 1 Bank Select 0

20:42:42.631 From USB Uno MIDI Interface Control 1 Bank Select (fine) 0
20:42:42.632 From USB Uno MIDI Interface Program 1 1
20:42:42.642 From USB Uno MIDI Interface Control 2 Bank Select 0
20:42:42.643 From USB Uno MIDI Interface Control 2 Bank Select (fine) 1
20:42:42.645 From USB Uno MIDI Interface Program 2 124
20:42:42.648 From USB Uno MIDI Interface Control 1 Bank Select 0
20:42:42.649 From USB Uno MIDI Interface Control 1 Bank Select (fine) 0
20:42:42.652 From USB Uno MIDI Interface Program 1 33

On entering MIDI mode (from Song mode):

20:43:34.580 From USB Uno MIDI Interface Control 1 Channel Volume (coarse) 127
20:43:34.581 From USB Uno MIDI Interface Control 1 Pan (coarse) 64
20:43:34.581 From USB Uno MIDI Interface Control 1 Expression (coarse) 127
20:43:34.582 From USB Uno MIDI Interface Control 2 Channel Volume (coarse) 127
20:43:34.583 From USB Uno MIDI Interface Control 2 Pan (coarse) 64
20:43:34.584 From USB Uno MIDI Interface Control 2 Expression (coarse) 127
20:43:34.584 From USB Uno MIDI Interface Control 3 Channel Volume (coarse) 127
20:43:34.585 From USB Uno MIDI Interface Control 3 Pan (coarse) 64
20:43:34.587 From USB Uno MIDI Interface Control 3 Expression (coarse) 127
20:43:34.587 From USB Uno MIDI Interface Control 4 Channel Volume (coarse) 127
20:43:34.587 From USB Uno MIDI Interface Control 4 Pan (coarse) 64
20:43:34.588 From USB Uno MIDI Interface Control 4 Expression (coarse) 127
20:43:34.589 From USB Uno MIDI Interface Control 5 Channel Volume (coarse) 127
20:43:34.590 From USB Uno MIDI Interface Control 5 Pan (coarse) 64
20:43:34.590 From USB Uno MIDI Interface Control 5 Expression (coarse) 127
20:43:34.591 From USB Uno MIDI Interface Control 6 Channel Volume (coarse) 127
20:43:34.592 From USB Uno MIDI Interface Control 6 Pan (coarse) 64

20:43:34.592 From USB Uno MIDI Interface Control 6 Expression (coarse) 127

20:43:34.593 From USB Uno MIDI Interface Control 7 Channel Volume (coarse) 127

20:43:34.594 From USB Uno MIDI Interface Control 7 Pan (coarse) 64

20:43:34.595 From USB Uno MIDI Interface Control 7 Expression (coarse) 127

20:43:34.596 From USB Uno MIDI Interface Control 8 Channel Volume (coarse) 127

20:43:34.596 From USB Uno MIDI Interface Control 8 Pan (coarse) 64

20:43:34.597 From USB Uno MIDI Interface Control 8 Expression (coarse) 127

20:43:34.598 From USB Uno MIDI Interface Control 9 Channel Volume (coarse) 127

20:43:34.598 From USB Uno MIDI Interface Control 9 Pan (coarse) 64

20:43:34.599 From USB Uno MIDI Interface Control 9 Expression (coarse) 127

20:43:34.600 From USB Uno MIDI Interface Control 10 Channel Volume (coarse) 127

20:43:34.601 From USB Uno MIDI Interface Control 10 Pan (coarse) 64

20:43:34.601 From USB Uno MIDI Interface Control 10 Expression (coarse) 127

20:43:34.602 From USB Uno MIDI Interface Control 11 Channel Volume (coarse) 127

20:43:34.603 From USB Uno MIDI Interface Control 11 Pan (coarse) 64

20:43:34.603 From USB Uno MIDI Interface Control 11 Expression (coarse) 127

20:43:34.604 From USB Uno MIDI Interface Control 12 Channel Volume (coarse) 127

20:43:34.605 From USB Uno MIDI Interface Control 12 Pan (coarse) 64

20:43:34.606 From USB Uno MIDI Interface Control 12 Expression (coarse) 127

20:43:34.607 From USB Uno MIDI Interface Control 13 Channel Volume (coarse) 127

20:43:34.607 From USB Uno MIDI Interface Control 13 Pan (coarse) 64

20:43:34.608 From USB Uno MIDI Interface Control 13 Expression (coarse) 127

20:43:34.609 From USB Uno MIDI Interface Control 14 Channel Volume (coarse) 127

20:43:34.610 From USB Uno MIDI Interface Control 14 Pan (coarse) 64

20:43:34.610 From USB Uno MIDI Interface Control 14 Expression (coarse) 127

20:43:34.611 From USB Uno MIDI Interface Control 15 Channel Volume (coarse) 127

20:43:34.612 From USB Uno MIDI Interface Control 15 Pan (coarse) 64

20:43:34.612 From USB Uno MIDI Interface Control 15 Expression (coarse) 127

20:43:34.613 From USB Uno MIDI Interface Control 16 Channel Volume (coarse) 127

20:43:34.614 From USB Uno MIDI Interface Control 16 Pan (coarse) 64

20:43:34.615 From USB Uno MIDI Interface Control 16 Expression (coarse) 127